


# PARTS LIST VIEW TERROVA




ITEM #	PART NUMBER	DESCRIPTION	QTY
1	2990270	I-PILOT CONTROLLER, TERROVA	1
2	2994170	REMOTE, ASSEMBLY I-PILOT	1
3	2372100	SCREW, #8-18 X 5/8" SS	4
4*	2377152	MANUAL, I-PILOT	1
5*	2377153	MANUAL, I-PILOT QUICK REFERENCE GUIDE	1
6*	2370817	LANYARD, REMOTE WITH CARABINEER	1

\* Not Shown In Exploded View

# INSTALLATION




## PARTS LIST VIEW RIPTIDE ST



ITEM #	PART NUMBER	DESCRIPTION	QTY
1	2990271	I-PILOT CONTROLLER, RIPTIDE ST	1
2	2994170	REMOTE, ASSEMBLY I-PILOT	1
3	2372100	SCREW, #8-18 X 5/8" SS	4
4*	2377152	MANUAL, I-PILOT	1
5*	2377153	MANUAL, I-PILOT QUICK REFERENCE GUIDE	1
6*	2370817	LANYARD, REMOTE WITH CARABINEER	1

\* Not Shown In Exploded View

# PARTS LIST VIEW POWERDRIVE V2




ITEM #	PART NUMBER	DESCRIPTION	QTY
1	2990272	I-PILOT CONTROLLER, POWERDRIVE V2	1
2	2994170	REMOTE, ASSEMBLY I-PILOT	1
3	2372100	SCREW, #8-18 X 5/8" SS	4
4	2224704	INSERT PLUG, BLACK SLOTTED	1
5	2376312	TIE, NYLON	5
6	2375403	HEAT SHRINK, .375 X 2 ADHESIVE LINED 3:1	4
7	2303430	SCREW - 1/4 - 20 X 5/8 - SELFTAP ZP	2
8*	2377152	MANUAL, I-PILOT	1
9*	2377153	MANUAL, I-PILOT QUICK REFERENCE GUIDE	1
10*	2370817	LANYARD, REMOTE WITH CARABINEER	1

\* Not Shown In Exploded View

# INSTALLATION



## PARTS LIST VIEW RIPTIDE SP



ITEM #	PART NUMBER	DESCRIPTION	QTY
1	2990273	I-PILOT CONTROLLER, RIPTIDE SP	1
2	2994170	REMOTE, ASSEMBLY I-PILOT	1
3	2372100	SCREW, #8-18 X 5/8" SS	4
4	2224705	INSERT PLUG, WHITE SLOTTED	1
5	2376312	TIE, NYLON	5
6	2375403	HEAT SHRINK, .375 X 2 ADHESIVE LINED 3:1	10
7	2332104	SCREW - 1/4 - 20 X 5/8 SS	2
8*	2377152	MANUAL, I-PILOT	1
9*	2377153	MANUAL, I-PILOT QUICK REFERENCE GUIDE	1
10*	2370817	LANYARD, REMOTE WITH CARABINEER	1

\* Not Shown In Exploded View